

HAND TRUCK HI-U EXTENSION INSTALLATION INSTRUCTIONS

PARTS LIST

DESCRIPTION	QTY.	PART NO.
Hi-U extension	1	Varies
Handle hardware (provided with complete hand truck order; if retrofitting, order hardware below)		--

TOOLS REQUIRED

- (1) #3 PHILLIPS HEAD SCREWDRIVER
- (1) 7/16" WRENCH

INSTALLATION INSTRUCTIONS

1. Remove the two 1/4"-20 pan head screws (A) and hex lock nuts (B) from one side at a time, leaving handle components in place.
2. Place the legs of Hi-U extension (C) between the handle components and so that the bottom of the legs rest on the top cross brace. Be sure that the holes in the Hi-U extension line up with the holes in the handle components and frame side rails.
3. Replace the 1/4"-20 pan head screws and hex lock nuts. Securely tighten the 1/4"-20 screws to 50-60 in.-lbs. torque.

Handle Part No. (model no.)	Screw Part No. (Qty required)	Lock Nut Part No. (Qty required)
301000 (#11)	80106 (4)	80675 (4)
301008 (#19)	80106 (4)	80675 (4)
301001 (#24)	80106 (4)	80675 (4)
301188 (#28)	80106 (4)	80675 (4)
30100 (#12)	80039 (4)	80675 (4)
86031 (#16)	80039 (4)	80675 (4)
30102 (#22)	80039 (4)	80675 (4)

